

Wireless Charging Stand - Kit

A 3D printable, rotating, glow-in-dark double helix with intergrated QI wireless charger.

Difficulty: Moderate
Platforms: Arduino

Estimated time: 3 days

License: GNU General Public License, version 3 or

later (GPL3+)



Items used in the project

Hardware components

- 1x Universal Qi Wireless Charging Transmitter
- 1x Usb Diy Connector Shell A Male Plug
- 1x Usb Diy Connector Shell Micro-b Plug
- 1x Usb 2.0a To Micro B 2.0 1.5m Blk
- 1x Drv8833 Dc/stepr Mtr Drivr Breakout Board
- 1x Reduction Stepper Motor 5vdc 32-step
- 8x M3 6.0mm Screw Zinc Plated Steel
- 3x Metal Oxide Resistors 100 Ohm 5% 1w
- 1x Arduino Nano Every
- 2x Spdt Slide Switch
- 4x Purple Clear 2200mcd
- 1x Stranded-core Wire Spool 25ft 22awg Blue
- 1x Stranded-core Wire Spool 25ft 22awg White

Software apps & online services

None

Hand tools & fabrication machines

None

Digital files

The schematics, CAD and code files are available via the Electromaker website at: https://www.electromaker.io/kits/wireless-charging-stand/guide


Instructions

Printing the parts:

There are eight 3D printed parts to this project which you will need to print, the largest print is the Double Helix. I printed

all the parts used in this tutorial in PLA. PETG, ABS or something similar should also be absolutely ?ne.





Helix.stl


Layer height: 0.15mm

Supports: No

Brim: No

Print time: about 12.5 hours

This part was printed in two di?erent types of PLA. The ?rst few millimetres was printed in a grey PLA which was then changed mid-print for some glow in the dark PLA. You can make the change manually on a Prusa Printer by going to 'Tune' -> 'Change Filament'. You can also schedule a ?lament change when slicing your model and generating the GCODE for it.



TopHousing.stl


Layer height: 0.20mm

Supports: No

Brim: No

Print time: 7 hours

This is the part we will use ?rst during the project assembly and houses the majority of the electronics.



BaseHousing.stl

Layer height: 0.15mm

Supports: No

Brim: Yes

Print time: 7 hours




MotorTopPlate.stl

Layer height: 0.20mm

Supports: Yes

Brim: No

Print time: 3 hours 20 minutes




Joiner.stl

Layer height: 0.15mm

Supports: No

Brim: Yes

Print time: 1 hour 10 minutes




Spine.stl

Layer height: 0.15mm

Supports: No

Brim: Yes

Print time: 13 hours 49 minutes



TopCover.stl

Layer height: 0.20mm

Supports: No

Brim: No

Print time: 1 hour 17 minutes

Begin assembling the Electronics



We'll start the assembly by installing the QI charger into the top housing.




Place the coil face down in its holder and use a few dabs of hot melt glue to keep it in position against the print.





Once the glue has cooled you can fold the circuit board carefully back over the rear of the coil and hold this in position by using two of the M3 x 6 screws in your kit. These need to be done up ?rmly, but be careful not to over tighten them.

Now we will create our own mini USB cable to connect the power from the QI charger to our Arduino board.



Prepare two 13cm lengths of wire and the Type A Male Connector and Type Micro B Male connector for this step.



With the pins of the Type A connector facing you and the USB plug away from you solder the grey wire to the pad on the left and the white wire to rightmost pad.





You can then ?nish the assembly of this end of the cable by push ?tting the two plastic halves of the connector around the electronics.



Before we solder the other end you'll need to take the small rubber sleeve from the Micro B connector and thread both the wire through it.

Start Soldering





With the micro B plug facing away from us and the side with three pads on it (not the side with two) facing upwards the grey wire is soldered to the left hand side and the white wire to the right hand side.







You can now slider the small rubber collar we put the wire through back up to meet the plug and then encase these in

the two rigid halves of the plugs shell.

For the next step prepare ?ve 40cm lengths of wire and your motor driver board.





Solder one end of each wire to following points on the board:

Ground

BOUT1


BOUT2

AOUT


AOUT2



Then use some masking tape or similar to label the other end of each wire. This will make it a lot easier to connect it to the stepper motor towards the end of this project.




Prepare two 12cm lengths of wire, a 20cm length of wire, one of the switches and the Arduino Every board for this step.







Solder one of the 12cm wires to the positive side of VMOTOR. The other end of the wire is soldered to one of the outside legs on the switch.





To the centre leg of the switch solder the other 12cm wire. Solder the other end to the VIN pin on the Arduino.






The 20cm length of wire is soldered between the negative side of VMOTOR on the motor shield and one of the GND


connections on the Arduino.

Let's begin to work on the base of the project. You will need the 'Base Housing' print, 'Joiner' and 'Motor Top Plate'.


Install the stepper motor








Taking the stepper motor and 'Motor Top Plate' to begin, apply plenty of hot melt glue to the recess shaped for the stepper. Insert the stepper motor (ensuring that you don't get any glue on the shaft) and press ?rmly against the printed part so that it is level as the glue cools.





Once the glue has cooled you can add some more to the rear of the tabs to help ensure it stays in place. This glue will be taking the weight of the double helix once the project is complete.





Add glue to the underside of the rim of the 'Base Housing' print. The 'Motor Top Plate' assembly is then inserted from below. Again push these two prints ?rmly together so that everything sets level.









Apply a small dab of glue the outside of the 'Joiner' print and insert this into the assembly we have just been working on. The long rod end is inserted ?rst and the shape of the part will ensure it is inserted in an orientation that will not block any cable runs which we will be using later. Insert it all the way in until the part touches the table.

Resistors, wires, switches and LED's






For this step prepare two 10cm lengths of wire and two 100 ohm resistors. Reduce the length of the legs on the resistor by cutting two-thirds o? from each side.






Solder one wire to one resistor and repeat with the other pair.




Solder one of the wires to D9 and the other to D10 on the Arduino.



Trim o? about one-third of the length of both legs on two LEDs. Take note of which leg was the longest of the two before you cut it and ensure it still is after you have cut it. This will help us identify which one is the anode (positive) end later.




Solder the longer and leg of each LED to each of the two resistors.






Now prepare two more wires, one 5cm long and the other 12cm long. Solder one to the unused leg of one of the LEDs and repeat with the other LED and wire.




Solder both the wires to the same outside leg of a new switch.






Attach an additional 10cm length of wire to the centre leg of this switch, and then solder the other end to GND on the Arduino.




Check the code


Now is a good time for us to upload the code and check some of our wirings so far. Connect your Arduino to your PC using the included USB cable and open the project's code in the Arduino IDE. There is a link to download the code towards the bottom of this page. (Or at the projects page on electromaker.io if you are reading a printed copy of these instructions).




If you have not used an Arduino Nano Every board before then you will most likely need to install the board in your IDE. This is as simple as opening the 'Tools' menu, then 'Boards' and clicking on 'Board Manager' at the top of the ?y-out list.



In the board manager that pops up, search for 'megaAVR' and install the latest version.





Go back to the Tools menu and ensure that the board type of 'Arduino Nano Every' is selected and that you have chosen the serial port which is connected to your Arduino.




Upload the code and if everything is correct the LEDs should begin to fade in and out slowly. If not, try the switch connected between the LEDs and the ground on the Arduino.

Final steps





Plug one end of the USB cable you assembled earlier into the Arduino and the other end into the QI charger module.



Add some hot melt glue to the top of the level split column and the take the LED with the longer wires attached and

attach it to the top of the column. You can carefully separate the legs of the LED to help it ?t on the column and prevent it from short-circuiting




Repeat the same with the LED, but this one is ?tted on the sloping face of the remaining split column.



Use more glue to ?x the switch for the LEDs at the top of one of the U shaped columns. The top of the switch should be ?ush with the top of this column. Take care that glue does not prevent the switch mechanism from actually switching.





Prepare ?ve 18cm wires and solder one to each of the following points on the motor driver.


AIN1

AIN2

SLP

BIN2

BIN1



The wires are then soldered onto the Arduino Nano Every as follows:

AIN1 -> D5

AIN2 -> D4


SLP -> 3.3V

BIN2 --> D7

BIN1 -> D6




Apply a generous helping of glue to the rear-side of the Arduino and ?x it in place on one side of the enclosure.



Glue the remaining switch to the unused switch holder. As before ensure that the switch is ?ush with the top and glue does not interfere with its operation.



Use another liberal helping of glue to ?x the motor driver into place. I put glue on the bottom of the enclosure and sidewall to hold the driver in position.





Connect the factory-made USB cable to the QI charger and route the cable through the outlet at the rear of the enclosure. Route the unconnected wire coming from the stepper motor along the same path as well.




The top cover can then be seated in the enclosure and screwed into place using two of your M3 x 6mm screws.




Thread the USB cable and stepper wires through the tunnel at the rear of the spine. This can then be ?tted together.



Thread the cable through the tunnel at the rear of the base housing and ?t these parts together.



To connect the stepper motor remove the plug at the end of its wires and strip their ends in preparation for soldering.



These are then soldered onto the labelled wires we have coming from the stepper motor driver board. They are to be connected as follows:

Red -> Ground

Pink —> AOUT2


Yellow —> BOUT2

Orange —> AOUT1

Blue --> BOUT1

Finishing up

Wrap some insulation tape around each of the solder joints (or use shrink wrap if you prefer) to prevent them from shortening the circuit.



The bottom cover can now be added and secured into place with the four remaining screws.



To help reduce noise from vibrations, cut three small lengths of a rubber band and glue these to the three feet.



The double helix that we printed earlier is added to the shaft of the stepper motor by aligning the shape on the bottom of the 3D print with the shaft itself. It will only ?t when the two are parallel.



As long as it is well balanced the only thing the 3D printed helix part should come into contact with is the shaft of the stepper motor. If you hear any scraping noises check that the edges of your prints are clean of any stray plastic and that the helix is well balanced.



If you wanted to as an optional step you can apply some super glue to between the spine and the top and bottom housings.

Project complete! The wireless charger embedded in the top is QI certi?ed so any QI compatible device can be charged. I've used mine to recharge my mobile phone and one of my ?lming lights which has a wireless QI receiver inbuilt.

The two switches on the underside of the top housing let you turn on or o? the LEDs and motor separately.

If you want to customise yours then feel free to design other objects to put on the turntable. Perhaps you could make a glow in the dark skeleton?



Have you enjoyed this Electromaker Kit?

Why not try one of the other kits in the range such as the Disco Helmet - Kit or the LED Mood Lamp - Kit?

Visit the Electromaker Kits section on our website to find out more: https://www.electromaker.io/kits